



## Service Installation: Stage Door Servo

October 11, 2018

SI-101118

Written by BTA

---

### Stage Door Servo Installation Guide

**Parts Needed:** Servo Kit {Servo, Wire Ties}

**Tools Needed:** 1/4" & 11/32" Nut Driver, Wire Cutters, Philips Screw Driver.

**Software Version must be at least Version 18.8.5**

**IT IS HIGHLY RECOMMENDED TO TAKE PICTURES OF ALL PARTS REMOVED AND WHERE THEY GO.**

**PLEASE READ THROUGH THIS GUIDE AND UNDERSTAND IT COMPLETELY BEFORE YOU START.**


**IF YOU NEED HELP CALL 833.API.HELP M-F 8AM – 5PM CENTRAL TIME.**

**IF YOU THINK THIS IS ABOVE YOUR ABILITIES SEEK A PROFESSIONAL TO PERFORM THIS!**


#### INSTRUCTIONS:

**WITH THE GAME TURNED OFF AND THE POWER CORD UNPLUGGED FROM THE OUTLET!**


Remove Monitor Cover and Store in a Safe Place "A". Cut the 2 Wire Ties "B" and Remove the Two Connectors from the Monitor "C". Remove the Two 1/4" Hex Standup Posts "B" and the Two Screws "D". Remove Monitor and Store in a Safe Place.



Lift the playfield fully so it is resting against the backbox, find the Stage IO board located on the bottom right side near the Stage on the underside of the playfield. Unplug the 2 black 1 white wire connector located in spot "0" (Stage Door Servo Connector), route wire so that it can be removed from the top of the playfield for Stage Door Servo removal.



With the playfield in the down position, remove the 4 screws and nuts from the Stage Door Servo and remove the servo and wire connector from the game.




With the Servo removed open the stage door half way.



Insert the new servo and make sure to reinstall the servo collar. Reinstall the 4 screws, reconnect the Servo Connector back into Slot “0” of the Stage IO Board. Reassemble the monitor utilizing the 2 hex spacers and 2 screws, make sure the 2 monitor connectors are inserted and wire tied to the hex spacer for strain relief. Reinstall the hood with the 2 screws.



With everything reassembled RECONNECT THE POWER CORD TO THE OUTLET AND POWER ON THE GAME. Enter the test mode go to UTILITIES>STAGE DOOR CALIBRATION. Follow the on-screen prompts. Exit Test Mode



Play a test game, everything should operate normally at this point, if not call the service help line

# 833-API-HELP