



Service Advisory: Coil Stop BBR Game: Oktoberfest

January 28, 2020

SA-12820

Written by B. Engler

REASON: Reports of Beer Barrel Ramp shot being difficult to make. Testing indicates that shortening the flipper stroke increases odds of making the BBR shot.

PARTS NEEDED: Coil Stop, Shipped to distributors. *P/N SUB0025-01*


TOOLS NEEDED: 5/32 Hex Wrench



P/N SUB0025-01
Longer coil stop insert

INSTRUCTIONS:

1. Turn Off power and unplug unit from AC source.
2. Open coin door.




3. Remove lock down bar.
4. Remove playfield glass, store in a safe place.



5. Lift playfield so it is resting against the head.

6. Remove the two 5/32 hex screws from the upper right flipper assembly. Swap the coil brackets.



7. Replace the 2 hex screws, *don't forget the lock washer on each screw.*
8. Install the playfield glass, lock down bar and close the coin door.
9. Plug the unit in and power up the game.
10. Test the game for as long as needed.

NEED HELP?

833-API-HELP